

T.P.E. OSSIE WRAPPER

SET UP INSTRUCTIONS

1. **Fit wheels to corresponding holes on each side frame to suit the pipe diameter you are going to wrap.**
2. **Fit roll of tape into machine making sure the end of the tape leads from the top of the roll to the left hand side. Replace side plate, spring and screwed knob.**
3. **Adjust the offset of the two side frames to achieve the specified overlap, this is done by loosening the 8mm & 12mm nuts on the back side of the machine and raising or lowering the leading end of the side frame, lock up both nuts. This adjustment may need to be done a couple of times to get the correct overlap.**
4. **The removable side frame has three positions for the centre hub. This adjustment allows the tape to pull square of the roll. A simple visual check is to look at the tape as it runs of the roll. The tape should be central and as close as possible to parallel between the frames.**
5. **Check the overlap adjustment again once you are satisfied with setting. Lock up adjustments. They should not need to be touched again until you change tape width or pipe size.**
6. **Should you have any questions or require additional information or spare parts call 617 3344 1066.**